

SOFT SIDED CAMERA & ACCESSORY BAGS



D773

Small neoprene bag
Fits all digital and 35mm compact cameras
2 storage compartments, 2 pockets,
media card and film storage
Hand, belt and shoulder strap
6"W x 7"H x 3.5"D



D777

All purpose bag
Nylon / briefcase style bag with multiple adjustable interior compartments
Perfect for camera equipment, video games or portable DVD players
Hand strap and adjustable shoulder strap
13.5"W x 10.5"H x 4.5D



D778

Micro pouch
1.5"W x 3"H x 1" D



D779

Mini pouch
2"W x 4"H x 1.5D



D775

Camera cache
Neoprene/nylon construction with
1 main compartment with a front
pocket that includes storage for
memory or film. Belt loop and
adjustable shoulder strap
4.5"W x 6"H x 4"D



D772

Compact neoprene pouch
1 Storage compartment, 1
storage pocket, media card
and film storage, belt and
shoulder strap
4"W x 6"H x 2.5"D



D771

Compact nylon pouch
1 storage compartment,
media card storage,
Belt and shoulder strap
4"W x 6.5"H x 2.5"D



D776

Camera caddy
Neoprene / nylon construction, adjustable 2 space main
compartment with closed front pocket and side mesh
pockets, memory card and film storage slots
Hand strap and adjustable shoulder strap
8.5W x 7.5"H x 6"D